

---

## **SECTION 15071 - MECHANICAL VIBRATION AND SEISMIC CONTROLS**

### **PART 1 - GENERAL**

#### **1.1 RELATED DOCUMENTS**

- A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 1 Specification Sections, apply to this Section.

#### **1.2 SUMMARY**

- A. This Section includes the following:
  - 1. Elastomeric isolation pads and mounts.
  - 2. Seismic snubbers.
  - 3. Restraining cables.
  - 4. Inertia vibration isolation equipment bases.

#### **1.3 DEFINITIONS**

- A.  $A_v$ : Effective peak velocity related acceleration coefficient.
- B. OSHPD: Office of Statewide Health Planning & Development for the State of California. OSHPD assigns a unique anchorage preapproval "R" number to each seismic restraint it tests. The number describes a specific device applied as tested.
- C. SMACNA: Sheet metal and air conditioning contractors National Association, Inc.

#### **1.4 PERFORMANCE REQUIREMENTS**

- A. Support mechanical equipment to comply with requirements of 2000 International Building Code.

#### **1.5 SUBMITTALS**

- A. Product Data: Include load deflection curves for each vibration isolation device.
- B. Shop Drawings: Signed and sealed by a qualified professional engineer. Include the following:
  - 1. Design Calculations: Calculate requirements for selecting seismic restraints.
- C. Welding certificates.
- D. Manufacturer Seismic Qualification Certification: Submit certification that all specified equipment will withstand seismic forces identified in "Performance Requirements" Article above. Include the following:
  - 1. Basis for Certification: Indicate whether withstand certification is based on actual test of assembled components or on calculations.
    - a. The term "withstand" means "the unit will remain in place without separation of any parts from the device when subjected to the seismic forces specified."

**1.6 QUALITY ASSURANCE**

- A. Seismic-restraint devices shall have horizontal and vertical load testing and analysis performed according to OSHPD and shall bear anchorage preapproval "R" number, from OSHPD or another agency acceptable to authorities having jurisdiction, showing maximum seismic-restraint ratings. Ratings based on independent testing are preferred to ratings based on calculations. If preapproved ratings are not available, submittals based on independent testing are preferred. Calculations (including combining shear and tensile loads) to support seismic-restraint designs must be signed and sealed by a qualified professional engineer. Testing and calculations must include both shear and tensile loads and 1 test or analysis at 45 degrees to the weakest mode.
- B. Welding: Qualify procedures and personnel according to AWS D1.1, "Structural Welding Code--Steel."

**1.7 COORDINATION**

- A. Coordinate size and location of concrete bases. Cast anchor-bolt inserts into base. Concrete, reinforcement, and formwork requirements are specified in Division 3.
- B. Coordinate installation of roof curbs, equipment supports, and roof penetrations. These items are specified in Division 7 Section "Roof Accessories."

**PART 2 - PRODUCTS****2.1 MANUFACTURERS**

- A. In other Part 2 articles where subparagraph titles below introduce lists, the following requirements apply for product selection:
  - 1. Available Manufacturers: Subject to compliance with requirements, manufacturers offering products that may be incorporated into the Work include, but are not limited to, the manufacturers specified.

**2.2 VIBRATION ISOLATORS**

- A. Available Manufacturers:
  - 1. Ace Mounting Co., Inc.
  - 2. Amber/Booth Company, Inc.
  - 3. B-Line Systems, Inc.
  - 4. California Dynamics Corp.
  - 5. Isolation Technology, Inc.
  - 6. Vibration Mountings & Controls/Korfund.
- B. Elastomeric Isolator Pads: Oil- and water-resistant elastomer or natural rubber, arranged in single or multiple layers, molded with a nonslip pattern and galvanized steel baseplates of sufficient stiffness for uniform loading over pad area, and factory cut to sizes that match requirements of supported equipment.
  - 1. Material: Standard neoprene AASHTO M 251.

- C. Spring Isolators: Freestanding, laterally stable, open-spring isolators.
  - 1. Outside Spring Diameter: Not less than 80 percent of the compressed height of the spring at rated load.
  - 2. Minimum Additional Travel: 50 percent of the required deflection at rated load.
  - 3. Lateral Stiffness: More than 80 percent of the rated vertical stiffness.
  - 4. Overload Capacity: Support 200 percent of rated load, fully compressed, without deformation or failure.
  - 5. Baseplates: Factory drilled for bolting to structure and bonded to 1/4-inch- (6-mm-) thick, rubber isolator pad attached to baseplate underside. Baseplates shall limit floor load to 100 psig (690 kPa).
  - 6. Top Plate and Adjustment Bolt: Threaded top plate with adjustment bolt and cap screw to fasten and level equipment.

## 2.3 SEISMIC-RESTRAINT DEVICES

- A. Available Manufacturers:
  - 1. Amber/Booth Company, Inc.
  - 2. B-Line Systems, Inc.
  - 3. California Dynamics Corp.
  - 4. Kinetics Noise Control, Inc.
  - 5. Loos & Co., Inc.; Cableware Technology Division.
  - 6. Mason Industries, Inc.
  - 7. TOLCO Incorporated.
  - 8. Unistrut Diversified Products Co.; Wayne Manufacturing Division.
  - 9. Vibration Eliminator Co., Inc.
  - 10. Vibration Isolation Co., Inc.
  - 11. Vibration Mountings & Controls/Korfund.
- B. Resilient Isolation Washers and Bushings: 1-piece, molded, bridge-bearing neoprene complying with AASHTO M 251 and having a durometer of [40] [50] [60], plus or minus 5, with a flat washer face.
- C. Seismic Snubbers: Factory fabricated using welded structural-steel shapes and plates, anchor bolts, and replaceable resilient isolation washers and bushings.
  - 1. Anchor bolts for attaching to concrete shall be seismic-rated, drill-in, and stud-wedge or female-wedge type.
  - 2. Resilient Isolation Washers and Bushings: 1-piece, molded, bridge-bearing neoprene complying with AASHTO M 251 and having a durometer of [40] [50] [60], plus or minus 5.
- D. Restraining Cables: Galvanized steel aircraft cables with end connections made of steel assemblies that swivel to final installation angle and utilize two clamping bolts for cable engagement.
- E. Anchor Bolts: Seismic-rated, drill-in, and stud-wedge or female-wedge type. Select anchor bolts with strength required for anchor and as tested according to ASTM E 488/E 488M.

## 2.4 VIBRATION ISOLATION EQUIPMENT BASES

- A. Available Manufacturers:
  - 1. Amber/Booth Company, Inc.
  - 2. California Dynamics Corp.
  - 3. Isolation Technology, Inc.
  - 4. Kinetics Noise Control, Inc.
  - 5. Mason Industries, Inc.
  - 6. Vibration Eliminator Co., Inc.
  - 7. Vibration Isolation Co., Inc.
  - 8. Vibration Mountings & Controls/Korfund.
- B. Inertia Base: Factory-fabricated, welded, structural-steel bases and rails ready for field-applied, cast-in-place concrete.
  - 1. Design Requirements: Lowest possible mounting height with not less than 1-inch (25-mm) clearance above the floor. Include equipment anchor bolts and auxiliary motor slide bases or rails. Include supports for suction and discharge elbows for pumps.
  - 2. Structural Steel: Steel shapes, plates, and bars complying with ASTM A 36/A 36M. Bases shall have shape to accommodate supported equipment.
  - 3. Support Brackets: Factory-welded steel angles on frame for outrigger isolation mountings and to provide for anchor bolts and equipment support.
  - 4. Fabrication: Fabricate steel templates to hold equipment anchor-bolt sleeves and anchors in place during placement of concrete. Obtain anchor-bolt templates from supported equipment manufacturer.

## 2.5 FACTORY FINISHES

- A. Manufacturer's standard prime-coat finish ready for field painting.
- B. Finish: Manufacturer's standard paint applied to factory-assembled and -tested equipment before shipping.
  - 1. Powder coating on springs and housings.
  - 2. All hardware shall be electrogalvanized. Hot-dip galvanize metal components for exterior use.
  - 3. Baked enamel for metal components on isolators for interior use.
  - 4. Color-code or otherwise mark vibration isolation and seismic-control devices to indicate capacity range.

## PART 3 - EXECUTION

### 3.1 EXAMINATION

- A. Examine areas and equipment to receive vibration isolation and seismic-control devices for compliance with requirements, installation tolerances, and other conditions affecting performance.
- B. Examine roughing-in of reinforcement and cast-in-place anchors to verify actual locations before installation.
- C. Proceed with installation only after unsatisfactory conditions have been corrected.

**3.2 INSTALLATION**

- A. Install roof curbs, equipment supports, and roof penetrations as specified in Division 7 Section "Roof Accessories."
- B. Install seismic snubbers on isolated equipment. Locate snubbers as close as possible to vibration isolators and bolt to equipment base and supporting structure.
- C. Install restraining cables at each trapeze and individual pipe hanger. At trapeze anchor locations, shackle piping to trapeze. Install cables so they do not bend across sharp edges of adjacent equipment or building structure.
- D. Install steel angles or channel, sized to prevent buckling, clamped with ductile-iron clamps to hanger rods for trapeze and individual pipe hangers. At trapeze anchor locations, shackle piping to trapeze. Requirements apply equally to hanging equipment. Do not weld angles to rods.
- E. Install resilient bolt isolation washers on equipment anchor bolts.

**3.3 EQUIPMENT BASES**

- A. Fill concrete inertia bases, after installing base frame, with [3000-psi (20.7-MPa)] concrete; trowel to a smooth finish.
  - 1. Cast-in-place concrete materials and placement requirements are specified in Division 3.
- B. Concrete Bases: Anchor equipment to concrete base according to supported equipment manufacturer's written instructions for seismic codes at Project site.
  - 1. Install dowel rods to connect concrete base to concrete floor. Unless otherwise indicated, install dowel rods on 18-inch (450-mm) centers around the full perimeter of the base.
  - 2. Install epoxy-coated anchor bolts for supported equipment that extend through concrete base and anchor into structural concrete floor.
  - 3. Place and secure anchorage devices. Use Setting Drawings, templates, diagrams, instructions, and directions furnished with items to be embedded.
  - 4. Install anchor bolts to elevations required for proper attachment to supported equipment.
  - 5. Install anchor bolts according to anchor-bolt manufacturer's written instructions.
  - 6. Cast-in-place concrete materials and placement requirements are specified in Division 3.

**3.4 ADJUSTING**

- A. Adjust isolators after piping systems have been filled and equipment is at operating weight.
- B. Adjust limit stops on restrained spring isolators to mount equipment at normal operating height. After equipment installation is complete, adjust limit stops so they are out of contact during normal operation.
- C. Adjust active height of spring isolators.
- D. Adjust snubbers according to manufacturer's written recommendations.
- E. Adjust seismic restraints to permit free movement of equipment within normal mode of operation.
- F. Torque anchor bolts according to equipment manufacturer's written recommendations to resist seismic forces.

3.5 CLEANING

- A. After completing equipment installation, inspect vibration isolation and seismic-control devices. Remove paint splatters and other spots, dirt, and debris.

3.6 DEMONSTRATION

- A. Engage a factory-authorized service representative to train Owner's maintenance personnel to adjust, operate, and maintain air-mounting systems. Refer to Division 1 Section "Closeout Procedures."

END OF SECTION 15071